



- Jumper in position 1 shorts G&R (as shown)
- Jumper in position 2 separates G&R
- Jumper in position 1 connects R to an external wire reference
- Jumper in position 2 connects R to internal probe reference site

G = Ground
R = Reference

SPECIFICATION

Connector 2x SAMTEC FOLC-110-01-S-Q

Mating Connector 2x SAMTEC MOLC-110-01-S-Q